



FIRST TIME INSTALLATION

- * REMOVE PARTS FROM INSIDE THE PACKAGE AND CHECK THEM ALL
- * CONTACT YOUR DEALER IF ANY PART IS MISSING OR DAMAGED
- * USE THE EQUIPMENT SPECIFIED FOR INSTALLATION

ASSEMBLY INSTRUCTIONS (BRACKET KIT)

Product Code: MB05043 (A/B-TYPE)

COMPATIBLE VEHICLES

- HND CRV (Mk3) SUV 07-11
- HND CRV (Mk4) SUV 12-18



Whatever product type you will use, Example of side step types;
Type A (Alyans, Sapphire, Emerald)
Type B (Brilliant, Another, Pearl, Ring, Plus) / Type E (Era)
Assemble the parts through the matching fixing holes.

Kullanacağınız ürün tipi hangisi ise, Parçaları ona uyumlu olan bağlantı deliklerinden birleştiriniz.

PACKAGE INCLUDED

1- M8x25 HEX BOLT	8	ZIPLOCK BAG
2- D8 WASHER	8	
3- M6x15 LOCK HEADED BOLT	8	
4- M6 HEX FLANGE NUT	8	

